

002-770 RAP Insufficient HDD capacity while processing the job template within a job.  
003-318 RAP IIT software failure.  
003-319 RAP IIT Video Driver Detection Fail.  
003-320 RAP IIT-ESS Communication Fail 1.  
003-321 RAP IIT-ESS Communication Fail 2.  
003-322 RAP IIT-ESS Communication Fail 3.  
003-323 RAP IIT-ESS Communication Fail 4.  
003-324 RAP IIT-ESS Communication Fail 5.  
003-325 RAP IIT-ESS Communication Fail 6.  
003-326 RAP IIT-ESS Communication Fail 7.  
003-327 RAP IIT-ESS Communication Fail 8.  
003-328 RAP IIT-ESS Communication Fail 9.  
003-329 RAP IIT-ESS Communication Fail 10.  
003-330 RAP IIT-ESS Communication Fail 11.  
003-331 RAP IIT-ESS Communication Fail 12.  
003-332 RAP IIT-ESS Communication Fail 13.  
003-333 RAP IIT-ESS Communication Fail 14.  
003-334 RAP IIT-ESS Communication Fail 15.  
003-335 RAP IIT-ESS Communication Fail 16.  
003-336 RAP IIT-ESS Communication Fail 17.  
003-337 RAP IIT-ESS Communication Fail 18.  
003-338 RAP IIT-ESS Communication Fail 19.  
003-339 RAP IIT-ESS Communication Fail 20.  
003-340 RAP IIT-ESS Communication Fail 21.  
003-341 RAP IIT-ESS Communication Fail 22.  
003-342 RAP IIT-ESS Communication Fail 23.  
003-343 RAP IIT-ESS Communication Fail 24.  
003-344 RAP Power on hotline failure.  
003-345 RAP X PIO Unmatch Fail 1.  
003-346 RAP X PIO Unmatch Fail 2.  
003-750 RAP Book Duplex-Insufficient Docs.  
003-751 RAP Under PANTHER Capacity (Scan).  
003-752 RAP This status code is displayed if 600dpi cannot be scanned (DADF).  
003-753 RAP This status code is displayed if over 300dpi cannot be scanned (DADF).  
003-754 RAP S2X Recoverable Error.  
003-755 RAP S2X Command Error.  
003-757 RAP This status code is displayed if over 400dpi cannot be scanned (DADF).

003-760 RAP Scan Settings Error.  
003-761 RAP Incorrect Paper Tray Size.  
003-763 RAP Adjustment Chart Not Found.  
003-764 RAP Adjustment Chart Not Found.  
003-780 RAP Scan Image Compression Error.  
003-795 RAP AMS Limit Error.  
003-940 RAP DAM Memory is insufficient.  
003-942 RAP Document Size Error.  
003-944 RAP Image Repeat Count Fail.  
003-946 RAP Copy Vertical/Horizontal Difference (APS).  
003-947 RAP Replaced Original Count Error.  
003-948 RAP Replaced Original Mismatch.  
003-952 RAP Return Documents Color mismatch.  
003-955 RAP Documents Size Exchange Error.  
003-956 RAP Documents Size Unknown Error.  
003-963 RAP No APS Object Tray.  
003-965 RAP ATS/APS No Paper. There is no paper in the trays that can be selected with APS.  
003-966 RAP AATS/APS No Destination Error.  
003-968 RAP Punch Position Error.  
003-969 RAP Punch Size Error.  
003-972 RAP Maximum Stored Page Over Flow.  
003-973 RAP Every Direction Difference.  
003-974 RAP Next Original Specification.  
003-977 RAP Document Miss Match (Multi Scan).  
003-978 RAP Color Document Mismatch (Multi Scan).  
003-980 RAP Staple Position Error.  
003-981 RAP Staple Size Error.  
003-982 RAP IITsc HDD Access Error.  
005-121 RAP DADF Feed Sensor ON Jam.  
005-122 RAP DADF Simplex/Side 1 Pre Reg Sensor ON Jam.  
005-123 RAP DADF Simplex/Side 1 Reg Sensor ON Jam.  
005-124 RAP DADF Lead Reg Sensor ON Jam.  
005-125 RAP DADF Reg Sensor OFF Jam.  
005-126 RAP DADF Out Sensor ON Jam.  
005-127 RAP DADF Out Sensor OFF Jam.  
005-128 RAP DADF Exit Sensor 1 ON Jam (Simplex Mode).  
005-129 RAP DADF Exit Sensor 1 OFF Jam (Simplex Mode).

005-130 RAP DADF Invert Sensor ON Jam (Duplex Mode).  
005-131 RAP DADF Invert Sensor On Jam (Inverting).  
005-132 RAP DADF Invert SNR on Jam 2.  
005-133 RAP DADF Invert Sensor OFF Jam.  
005-134 RAP DADF Invert SNR off Jam (Inv).  
005-135 RAP DADF Pre Reg Sensor ON Jam (Invert).  
005-136 RAP DADF Reg Sensor ON Jam (Invert).  
005-137 RAP DADF Exit Sensor 2 ON Jam.  
005-138 RAP DADF Exit Sensor 1 ON Jam.  
005-139 RAP DADF Invert SNR off Jam.  
005-141 RAP DADF Feed Sensor OFF Jam.  
005-142 RAP DADF Exit Sensor 1 OFF Jam (Duplex Mode).  
005-143 RAP DADF Exit Sensor 2 OFF Jam.  
005-144 RAP DADF Too First Pre Reg Sensor ON Jam.  
005-145 RAP DADF Reg Sensor Off Jam (Invert).  
005-146 RAP DADF Pre Reg Sensor Off Jam.  
005-147 RAP DADF Pre Reg Sensor Off Jam (Invert).  
005-150 RAP DADF Feed Sensor OFF Jam (Perforated Original Mode).  
005-151 RAP DADF Pre Reg Sensor OFF Jam (Perforated Original Mode).  
005-152 RAP DADF Reg Sensor OFF Jam (Perforated Original Mode).  
005-153 RAP DADF Reg Sensor OFF Jam (Perforated Original Mode).  
005-154 RAP DADF Out Sensor OFF Jam (Perforated Original Mode).  
005-155 RAP DADF Exit Sensor 1 OFF Jam (Perforated Original Mode) (Simplex).  
005-156 RAP DADF Exit Sensor 1 OFF Jam (Perforated Original Mode) (Duplex).  
005-157 RAP DADF Invert Sensor OFF Jam (Perforated Original Mode).  
005-158 RAP DADF Exit Sensor 2 OFF Jam (Perforated Original Mode).  
005-160 RAP DADF Tray Lift Up Fail (Document Set) (Within Job).  
005-190 RAP DADF Feed Motor Logic Jam.  
005-194 RAP Size Mismatch Jam on Slow Scan Mix Size.  
005-195 RAP Size Mismatch Jam on No Mix Size.  
005-196 RAP Size Mismatch Jam on No Mix Size.  
005-197 RAP Prohibit Combine Size Jam.  
005-198 RAP Too Short Size Jam.  
005-199 RAP Too Long Size Jam.  
005-275 RAP DADF RAM Fail.  
005-280 RAP DADF EEPROM Fail.  
005-282 RAP DADF Tray Lift Up Fail (No Document).

005-283 RAP DADF Stack Height Sensor Logic Fail.  
005-284 RAP DADF APS Sensor Logic Fail.  
005-285 RAP DADF Nudger Lift Up Fail.  
005-286 RAP DADF Feed Out Sensor Fail.  
005-303 RAP DADF Tray Interlock is open.  
005-304 RAP Platen Interlock Open.  
005-305 RAP DADF Feeder Cover Interlock Open (Run).  
005-306 RAP DADF Tray Interlock Open (Run).  
005-308 RAP The DADF L/H Cover Interlock is open.  
005-309 RAP DADF L/H Cover Interlock Open (Run).  
005-906 RAP DADF Feed Sensor Static Jam.  
005-907 RAP DADF Pre Reg Sensor Static Jam.  
005-908 RAP DADF Reg Sensor Static Jam.  
005-909 RAP DADF Lead Reg Sensor Static Jam..  
005-910 RAP DADF Out Sensor Static Jam.  
005-911 RAP DADF Exit Sensor 1 Static Jam.  
005-912 RAP DADF Exit Sensor 2 Static Jam.  
005-913 RAP DADF Invert Sensor Static Jam.  
005-914 RAP DADF No. 1/2/3 APS Sensor Static Jam.  
005-915 RAP DADF No. 1 APS Sensor Static Jam.  
005-916 RAP DADF No. 2 APS Sensor Static Jam.  
005-917 RAP DADF No. 3 APS Sensor Static Jam.  
005-918 RAP DADF Invert Sensor 2 Static Jam.  
005-919 RAP DADF Tray Lift Up Fail (Document Set).  
005-940 RAP DADF No Original Fail.  
005-941 RAP DADF Not Enough Document.  
005-942 RAP DADF Tray Stack Over Fail.  
010-311 RAP Fuser Heat Roll STS-1 Disconnection Fail. It was detected that fuser heat roll STS-1 disconnected.  
010-319 RAP Fuser NC Sensor Differential Amp Fail.  
010-320 RAP Heat Roll Over Heat Fail.  
010-321 RAP Fuser Nip Fail.  
010-322 RAP Fuser NC Center Sensor Disconnection Fail. (Fuser Temperature Sensor Fail).  
010-323 RAP Fuser Rear Sensor Disconnection Fail. (Fuser Temperature Sensor Fail).  
010-324 RAP Fuser NVM Fail.  
010-326 RAP Wait Heat Roll Fuser On Time Fail.  
010-327 RAP Standby Heat Roll Fuser On Time Fail.  
010-330 RAP Fuser Motor Fail.

010-420 RAP Fuser Assembly Life Near End.  
010-421 RAP Fuser Assembly Life End.  
012-112 RAP Finisher Interface Entrance Sensor ON.  
012-113 RAP Booklet In Sensor ON Jam.  
012-114 RAP Booklet In Sensor OFF Jam.  
012-115 RAP Booklet Folder Roll Exit Sensor ON Jam.  
012-125 RAP Gate Sensor ON JAM: Finisher.  
012-132 RAP Finisher Transport Entrance Sensor ON Jam (Long).  
012-142 RAP Buffer Path Sensor ON Jam A.  
012-151 RAP Compile Exit Sensor OFF Jam.  
012-152 RAP Compile Exit Sensor ON Jam A.  
012-161 RAP Set Eject Jam.  
012-162 RAP Finisher Interface EXIT. Sensor ON Jam.  
012-171 RAP Top Tray Exit Sensor ON Jam A.  
012-172 RAP Top Tray Exit Sensor OFF Jam A.  
012-180 RAP Booklet Folder Roll Exit Sensor OFF Jam.  
012-211 RAP Stacker Tray Fail.  
012-212 RAP Stacker Tray Upper Limit Fail.  
012-213 RAP Stacker Tray Lower Limit Fail.  
012-221 RAP Tamper Home Sensor ON Fail.  
012-223 RAP Tamper Home Sensor OFF Fail.  
012-224 RAP Rear Tamper Home Sensor OFF Fail.  
012-225 RAP Booklet Tamper F Home Sensor ON Fail.  
012-226 RAP Booklet Tamper F Home Sensor OFF Fail.  
012-227 RAP Booklet End Guide Home Sensor OFF Fail.  
012-228 RAP Booklet End Guide Home Sensor ON Fail.  
012-229 RAP Booklet Tamper R Home Sensor ON Fail.  
012-230 RAP Booklet Tamper R Home Sensor OFF Fail.  
012-243 RAP Booklet Knife Home Sensor ON Fail.  
012-246 RAP Booklet Stapler Fail.  
012-247 RAP Side Regi Sensor OFF Fail.  
012-260 RAP Eject Clamp Up Sensor ON Fail.  
012-261 RAP Booklet Knife Folding SNR Fail.  
012-263 RAP Finisher Rear Tamper Home Sensor ON.  
012-264 RAP Booklet Drawer Broken Fail.  
012-265 RAP Booklet Knife Home Sensor OFF Fail.  
012-266 RAP Booklet Compiler No Paper Sensor Fail.

012-270 RAP Top Offset Home Sensor ON Fail: Finisher.  
012-271 RAP Top Offset Home Sensor OFF Fail: Finisher.  
012-282 RAP Eject Clamp Up Sensor OFF Fail.  
012-283 RAP Finisher Set Clamp Home Sensor ON Fail.  
012-284 RAP Finisher Set Clamp Home Sensor OFF Fail.  
012-291 RAP Stapler Fail.  
012-295 RAP Finisher Stapler Move Sensor On Fail.  
012-296 RAP Finisher Stapler Move Sensor OFF Fail.  
012-300 RAP Finisher Eject Cover Open (Compiler Cover).  
012-302 RAP Finisher Front Door Interlock Open.  
012-307 RAP Booklet Drawer Set Fail.  
012-320 RAP Punch Home Sensor ON Fail.  
012-321 RAP Punch Home Sensor OFF Fail.  
012-322 RAP Puncher Move Home Sensor OFF Fail.  
012-323 RAP Puncher Move Home Sensor On Fail.  
012-325 RAP Side Regi Home Sensor On Fail.  
012-330 RAP Decurler Cam Home Sensor OFF Fail.  
012-332 RAP Decurler Cam Home Sensor ON Fail.  
012-334 RAP Download Mode Fail.  
012-335 RAP Booklet Sub CPU Communication Fail.  
012-900 RAP Buffer Path Sensor Static Jam.  
012-901 RAP Finisher Paper Remains at H-Transport Entrance.  
012-902 RAP Finisher Paper Remains H-Transport Exit.  
012-903 RAP Compile Exit Sensor Static Jam.  
012-905 RAP Compile Tray No Paper Sensor Static Jam.  
012-907 RAP Top Tray Exit Sensor Static Jam.  
012-920 RAP Gate Sensor static JAM (to Top Tray) A: Finisher.  
012-932 RAP Gate SNR static JAM (to Stacker Tray) A.  
012-934 RAP Gate SNR static JAM (to Stacker Tray) C.  
012-935 RAP Finisher Paper Remains at Transport Entrance Sensor.  
012-936 RAP Paper Remain at Booklet In SNR A.  
012-949 RAP Finisher Punch DustBox Miss Set.  
013-902 RAP Booklet Compile No Paper Sensor Static Jam.  
013-903 RAP Booklet Folder Roll Exit Sensor Static Jam.  
016-210 RAP Software Option Fail (HDD Not Exist).  
016-211 RAP Software Option Fail (System Memory Low Volume).  
016-212 RAP SW Option Fail (Page Memory Low).

016-213 RAP SW Option Fail (Printer CARD Not Exist).  
016-215 RAP SW Option Fail (JPEG Board Not Exist).  
016-216 RAP SW Option Fail (Ext Memory Not Exist).  
016-217 RAP SW Option Fail (Controller ROM not Printer kit).  
016-218 RAP Because PS Kit is not installed, XDOD functions cannot be fulfilled.  
016-219 RAP License is required (Printer Kit).  
016-220 RAP S2X Unrecoverable Error.  
016-221 RAP S2X Communication Error.  
016-222 RAP S2X Self-Diag Error.  
016-223 RAP SS2X SDRAM Error.  
016-224 RAP S2X PCI Reg Error.  
016-225 RAP S2X ROM CheckSum Error.  
016-226 RAP S2X IIT Connection Error.  
016-227 RAP S2X DDR Error.  
016-228 RAP S2X Image Processing Error.  
016-229 RAP SW Option Fail (FCW-UI Not Exist).  
016-311 RAP The scanner was not detected.  
016-315 RAP NIIT Interface Fail.  
016-316 RAP Page Memory Not Detected.  
016-317 RAP Page Memory Broken-Standard.  
016-318 RAP Page Memory Broken-Option.  
016-320 RAP A fatal error with doc conversion software was detected.  
016-322 RAP JBA Account Full.  
016-450 RAP SMB Host Name Duplicated.  
016-454 RAP DNS Renewal Failure of Dynamic.  
016-455 RAP SNTP Server Time Out.  
016-456 RAP SNTP Time Asynchronous.  
016-503 RAP SMTP Server Address Resolution Fail.  
016-504 RAP POP Server Address Resolution Fail.  
016-505 RAP POP Authentication Fail.  
016-600 RAP KO Authentication Locked.  
016-601 RAP Illegal Access Detection.  
016-647 RAP With APS selected or with APS set up, there were no trays loaded with paper sizes for Auto Paper Selection.  
016-648 RAP Job with Booklet selected was discontinued because it had a cover with an image, a divider, or a blank page.  
016-701 RAP Out of ART EX Memory.  
016-702 RAP Out of Page Buffer.  
016-703 RAP Email to Invalid Box.

016-704 RAP Mailbox is Full.  
016-705 RAP Secure Print Fail.  
016-706 RAP Max. User Number Exceeded.  
016-707 RAP Sample Print Fail.  
016-708 RAP HD Full by Annotation/Watermark Image.  
016-709 RAP ART EX Command Error.  
016-710 RAP Delayed Print Fail.  
016-711 RAP Tried to send data whose size is over the system data upper limit.  
016-712 RAP Under PANTHER Capacity (I-Formatter).  
016-713 RAP Security Box Password Error.  
016-714 RAP Security Box is not Enabled.  
016-716 RAP TIFF Data Overflow.  
016-718 RAP Out of PCL6 Memory.  
016-719 RAP Out of PCL Memory.  
016-720 RAP PCL Command Error.  
016-721 RAP Other Error.  
016-722 RAP Job Cancel by Staple Position NG.  
016-723 RAP Job Cancel by Punch Position NG.  
016-724 RAP Complex Position Error of Staple and Punch.  
016-726 RAP PDL Auto Switch Fail.  
016-728 RAP Unsupported TIFF Data.  
016-729 RAP TIFF Data Size too Big.  
016-730 RAP Unsupported ART Command.  
016-731 RAP Invalid TIFF Data.  
016-732 RAP Form Not Registered.  
016-733 RAP Destination Address Resolution Error.  
016-734 RAP Simple Transmission report invocation error.  
016-735 RAP Updating Job Template.  
016-736 RAP Remote directory lock error. Lock directory creation failed.  
016-737 RAP Remote lock directory remove error.  
016-738 RAP PS Booklet Print Output Paper Size is illegal.  
016-739 RAP Mismatch between PS Booklet Doc and Output Paper.  
016-740 RAP PS Booklet Output Tray is incorrect.  
016-746 RAP Unsupported PDF File.  
016-748 RAP HD Full.  
016-749 RAP JCL Syntax Error.  
016-751 RAP PDF Error.

016-752 RAP PDF Short of Memory.  
016-753 RAP PDF Password Mismatched.  
016-754 RAP PDF LZW Not Installed.  
016-755 RAP PDF Print Prohibited.  
016-756 RAP Auditron-Prohibit Service.  
016-757 RAP Auditron-Invalid User.  
016-758 RAP Auditron-Disabled Function.  
016-759 RAP Auditron-Reached Limit.  
016-760 RAP PS Decompose Failure.  
016-761 RAP FIFO Empty.  
016-762 RAP Print LANG Not Installed.  
016-764 RAP SMTP Server Connect Error.  
016-765 RAP SMTP Server HD Full.  
016-766 RAP SMTP Server File System Error.  
016-767 RAP Invalid E-mail Address.  
016-768 RAP Invalid Sender Address.  
016-769 RAP SMTP Server Unsupported DSN.  
016-771 RAP Scan Data Repository ERR.  
016-772 RAP Scan Data Repository ERR.  
016-773 RAP Invalid IP Address.  
016-774 RAP HD Full-Compression Convert.  
016-775 RAP HD Full-Image Convert.  
016-776 RAP Image Convert ERR.  
016-777 RAP HD Access ERR-Image Convert.  
016-778 RAP HD Full-Scan Image Convert.  
016-779 RAP Scan Image Conversion Error.  
016-780 RAP HD Access ERR-Image Convert.  
016-781 RAP Scan Server Connect ERR.  
016-782 RAP Scan Server Login ERR.  
016-783 RAP Invalid Server Path.  
016-784 RAP Server Write ERR.  
016-785 RAP Server HD Full.  
016-786 RAP HD Full-Scan Write ERR.  
016-787 RAP Invalid Server IP ADD.  
016-788 RAP Retrieve to Browser Failed.  
016-789 RAP HD Full-Job Memory.  
016-791 RAP File Retrieve Fail.

016-792 RAP Specified Job Not Found.  
016-793 RAP MF I/O HD Full.  
016-794 RAP Media Reader: Media No Insert.  
016-795 RAP Media Reader: Format Error.  
016-796 RAP Document insert operation error.  
016-797 RAP Media Reader: Image File Read Error.  
016-798 RAP No Trust Marking Option.  
016-799 RAP Print Instruction Fail.  
016-940 RAP With Duplex Output selected, a size difference between side 1 and side 2 was detected.  
016-941 RAP With Booklet selected, mixed-in-size/orientation pages with images were detected.  
016-942 RAP After a duplexed page was deleted, a size difference between side 1 and side 2 was detected.  
016-943 RAP After a document or divider was inserted, a size difference between side 1 and side 2 was detected.  
016-944 RAP Documents were merged, including the cover with an image, or a document with a divider.  
016-945 RAP A document unavailable for duplex print was inserted after a document available for Duplex was inserted.  
016-946 RAP A document or a divider was inserted after the cover or divider page.  
016-949 RAP The user inserted a document different in size/orientation from the page to be processed.  
016-981 RAP A failure in access to HDD.  
016-982 RAP HDD Access Error 2.  
016-985 RAP Data Size Over Flow (Scan to Email).  
024-340 RAP IOT-ESS Communication Failure 1.  
024-341 RAP IOT-ESS Communication Failure 2.  
024-342 RAP IOT-ESS Communication Failure 3.  
024-343 RAP IOT-ESS Communication Failure 4.  
024-345 RAP IOT-ESS Communication Failure 5.  
024-346 RAP IOT-ESS Communication Failure 6.  
024-347 RAP IOT-ESS Communication Failure 7.  
024-348 RAP IOT-ESS Communication Failure 8.  
024-349 RAP IOT-ESS Communication Failure 9.  
024-350 RAP IOT-ESS Communication Failure 10.  
024-351 RAP IOT-ESS Communication Failure 11.  
024-352 RAP IOT-ESS Communication Failure 12.  
024-353 RAP IOT-ESS Communication Failure 13.  
024-354 RAP IOT-ESS Communication Failure 14.  
024-355 RAP IOT-ESS Communication Failure 15.  
024-356 RAP IOT-ESS Communication Failure 16.  
024-357 RAP IOT-ESS Communication Failure 17.  
024-358 RAP IOT-ESS Communication Failure 18.

024-359 RAP IOT-ESS Communication Failure 19.  
024-360 RAP IOT-ESS Initialization Failure.  
024-361 RAP Invalid IOT PaperSizeGroup Information.  
024-362 RAP Page Sync Illegal Start.  
024-363 RAP Page Sync Illegal Stop.  
024-364 RAP DMA Transfer Failure.  
024-365 RAP Overflow on the Loop Back Write.  
024-366 RAP JBIG Library Other Failure.  
024-367 RAP Decompress Other Failure.  
024-368 RAP PCI Error.  
024-370 RAP Marker Code Detect Failure.  
024-371 RAP IOT-ESS Communication Failure 21.  
024-372 RAP IOT-ESS Communication Failure 22.  
024-373 RAP IOT-ESS Communication Failure 23.  
024-374 RAP Regi Con PLL Parameter Failure.  
024-375 RAP IOT-ESS Communication Failure 24.  
024-600 RAP Billing master counter repair.  
024-601 RAP Billing backup counter #1 repair.  
024-602 RAP Billing backup counter #2 repair.  
024-603 RAP SWKey master counter repair.  
024-604 RAP SWKey backup counter #1 repair.  
024-605 RAP SWKey backup counter #2 repair.  
024-606 RAP Production Number/Serial Number Failure.  
024-746 RAP Selected Paper Tray Parameter Mismatch.  
024-747 RAP Print Instruction Failure.  
024-910 RAP Tray 1 Size Mismatch.  
024-911 RAP Tray 2 Size Mismatch.  
024-912 RAP Tray 3 Size Mismatch.  
024-913 RAP Tray 4 Size Mismatch.  
024-914 RAP Tray 6 Size Mismatch.  
024-915 RAP Tray 7 Size Mismatch.  
024-917 RAP Stacker Tray Staple Set Over Count.  
024-919 RAP Face UP Tray Close.  
024-920 RAP Face Down Tray 1 Paper FULL.  
024-922 RAP Face Down Tray 2 Paper FULL.  
024-923 RAP Operation Yellow Toner Empty.  
024-924 RAP Operation Magenta Toner Empty.

024-925 RAP Operation Cyan Toner Empty.  
024-926 RAP Punch Dust Box Missing Set.  
024-927 RAP Offset Catch Tray Full Stack.  
024-930 RAP Stacker Tray Full (Small Size Full).  
024-934 RAP Paper type mismatch.  
024-935 RAP Tray 1 Paper Mismatch.  
024-936 RAP Tray 2 Paper Mismatch.  
024-937 RAP Tray 3 Paper Mismatch.  
024-938 RAP OHP kind Mismatch at Tray 4 (Not White Frame OHP).  
024-939 RAP Transparency type mismatch (No white border).  
024-940 RAP Folder Tray Out of Place.  
024-941 RAP Folder Tray Full Stack.  
024-942 RAP Booklet Sheets Over Count.  
024-943 RAP Booklet Low Staple.  
024-945 RAP Booklet Full Stack.  
024-946 RAP Tray 1 Not In Position.  
024-947 RAP Tray 2 Not In Position.  
024-948 RAP Tray 3 Not In Position.  
024-949 RAP Tray 4 Not In Position.  
024-950 RAP Tray 1 No Paper.  
024-951 RAP Tray 2 No Paper.  
024-952 RAP Tray 3 No Paper.  
024-953 RAP Tray 4 No Paper.  
024-954 RAP MSI No Paper.  
024-955 RAP Tray 6 No Paper.  
024-956 RAP Tray 7 No Paper.  
024-957 RAP Interposer No Paper.  
024-958 RAP MSI Size Mismatch.  
024-959 RAP Tray 1 Paper Size Mismatch.  
024-960 RAP Tray 2 Paper Size Mismatch.  
024-961 RAP Tray 3 Paper Size Mismatch.  
024-962 RAP Tray 4 Paper Size Mismatch.  
024-965 RAP ATS/APS No Paper.  
024-966 RAP ATS/APS No Destination Error.  
024-967 RAP Different Width Mix Paper Detect (Staple Job).  
024-968 RAP Stapler/Punch Batting.  
024-969 RAP Different Width Mix Punch.

024-970 RAP Tray 6 Not In Position.  
024-971 RAP Tray 7 Not In Position.  
024-972 RAP Tray 6 Paper Size Mismatch.  
024-973 RAP Tray 7 Paper Size Mismatch.  
024-974 RAP Interposer Tray Size Mismatch.  
024-975 RAP Booklet Sheets Over Count (Not Field Attachment).  
024-976 RAP Finisher Staple Status incorrect.  
024-977 RAP Stapler Feed Ready Failure.  
024-978 RAP Booklet Stapler incorrect.  
024-979 RAP Stapler Near Empty.  
024-980 RAP Finisher Stacker Tray Full.  
024-981 RAP Finisher Top Tray Full.  
024-982 RAP Stacker Lower Safety Warning.  
024-983 RAP Booklet Tray Full.  
024-984 RAP Booklet Low Staple F.  
024-985 RAP SMH Stop Check.  
024-987 RAP Envelope Folder Tray Full.  
024-988 RAP Envelope Folder Tray Set Failure.  
024-989 RAP Booklet Low Staple R.  
024-990 RAP Punch Dust Full.  
025-596 RAP Diag HDD Failure 1.  
025-597 RAP Diag HDD Failure 2.  
027-452 RAP Duplicate IP address.  
027-500 RAP SMTP Server Address Resolution Failure.  
027-501 RAP POP Server Address Resolution Failure.  
027-502 RAP POP Authentication Failure.  
027-700 RAP Media Failure.  
027-701 RAP Media Not Found.  
027-702 RAP Media Data Not Found / Not Supported.  
027-703 RAP Media Reader Failure / Disconnected.  
027-706 RAP Certificate not found.  
027-707 RAP Certificate expired.  
027-708 RAP Certificate untrusted.  
027-709 RAP Certificate revoked.  
027-710 RAP S/MIME mail was disabled.  
027-711 RAP S/MIME mail sender certificate not found.  
027-712 RAP S/MIME mail sender certificate not valid.

027-713 RAP S/MIME mail was altered.  
027-714 RAP S/MIME mail sender impersonation.  
027-715 RAP S/MIME mail certificate not supported.  
027-716 RAP No-Signed mail receipt was rejected.  
027-720 RAP Ext Srv. Host Not Found. A server specified for a remote application was not found, or DNS resolution was not possible.  
027-721 RAP Ext Srv. Not Found.  
027-722 RAP Ext Srv. Timeout Failure.  
027-723 RAP Ext Srv. Authentication Failure.  
027-724 RAP Ext Srv. Access Failure.  
027-725 RAP Ext Srv. Operation Failure.  
027-726 RAP Ext Srv. Unknown State.  
027-727 RAP Ext Srv. Req Invalid Parameters.  
027-728 RAP Ext Srv. Required File Exceeded.  
027-737 RAP Template Server Read Error.  
027-739 RAP Invalid Template Server Path.  
027-740 RAP Template Server Login Error.  
027-741 RAP Template Server Connect Failure.  
027-742 RAP HD File System Full.  
027-743 RAP Template Server Install Error.  
027-744 RAP Template Server ADD Error.  
027-745 RAP Template Server ADD Error.  
027-746 RAP Job Template Pool Server Not Ready.  
027-751 RAP Job Template Analysis Error.  
027-752 RAP Must User un Inputting.  
027-753 RAP Job Flow Service Request Disabled.  
027-760 RAP XJT Command Failure.  
027-770 RAP PDL Error.  
027-771 RAP DFE Disk Full.  
027-796 RAP Email Not Printed.  
027-797 RAP Invalid Output Destination.  
042-313 RAP Rear Cooling Fan Failure.  
042-320 RAP Yellow Drum Motor Drive Failure.  
042-321 RAP Magenta Drum Motor Drive Failure.  
042-322 RAP Cyan Drum Motor Drive Failure.  
042-323 RAP Black Drum Motor Drive Failure.  
042-324 RAP IBT Drive Motor Failure.  
042-325 RAP Main Motor Failure.

042-326 RAP Belt Home Position too long.  
042-327 RAP Belt Position Failure.  
042-328 RAP Belt Edge Sensor Failure.  
042-330 RAP Fuser Exhaust Fan Failure.  
042-331 RAP Blower Motor Fan Failure.  
042-600 RAP Belt Walk Failure.  
042-601 RAP Belt Edge Learn Failure.  
042-602 RAP Belt Edge Check Failure.  
042-603 RAP Suction Filter Life End Failure.  
045-310 RAP Image Ready NG.  
045-311 RAP Controller Comm Failure.  
045-312 RAP Driver Connect Failure.  
047-210 RAP OCT Offset Failure.  
047-310 RAP MCU-Finisher Communication Failure.  
061-310 RAP Clapper 1 Failure.  
061-311 RAP Clapper 2 Failure.  
061-313 RAP SOS Long Failure Magenta.  
061-315 RAP SOS Long Failure Black.  
061-317 RAP SOS Short Failure.  
061-319 RAP SOS Short Failure Black.  
061-320 RAP Polygon Motor Failure.  
061-321 RAP ROS Motor Failure.  
061-323 RAP No SOS Failure.  
061-324 RAP No SOS Failure.  
061-325 RAP No SOS Failure.  
061-326 RAP ROS Connect Failure Yellow.  
061-327 RAP ROS Connect Failure.  
061-328 RAP ROS Connect Failure.  
061-329 RAP ROS Connect Failure Black.  
061-334 RAP ROS Y/M VDD Failure.  
061-335 RAP ROS C/K VDD Failure.  
061-336 RAP ROS Y/M VDD Down Failure.  
061-337 RAP ROS C/K VDD Down Failure.  
061-338 RAP SOS Stop Magenta Failure.  
061-339 RAP SOS Stop Black Failure.  
061-340 RAP ROS LD Failure Black.  
061-341 RAP ROS LD Failure Yellow.

061-342 RAP ROS LD Failure Magenta.  
061-343 RAP ROS LD Failure Cyan.  
061-600 RAP ROS Data Failure Yellow.  
061-601 RAP ROS Data Failure Magenta.  
061-602 RAP ROS Data Failure Cyan.  
061-603 RAP ROS Data Failure Black.  
061-604 RAP LD Alarm Yellow.  
061-605 RAP LD Alarm Magenta.  
061-606 RAP LD Alarm Cyan.  
061-607 RAP LD Alarm Black.  
062-210 RAP IISS Hot Line Failure.  
062-211 RAP IIT/IPS EEPROM Failure (IPS).  
062-220 RAP IPS-EXT Connection Failure.  
062-277 RAP IIT/IPS-DADF Communication Failure.  
062-278 RAP IIT-Extension Communication Failure.  
062-300 RAP Platen Interlock Open.  
062-310 RAP IIT/IPS-ESS Communication Failure.  
062-311 RAP IIT Software Logic Failure.  
062-321 RAP IPS-YATA Connection Failure.  
062-322 RAP EXT-YATA Connection Failure.  
062-323 RAP YATA PWBA Failure.  
062-345 RAP IIT/IPS EEPROM Failure (IIT).  
062-355 RAP IPS Fan Failure.  
062-356 RAP Lamp Fan Failure.  
062-357 RAP CCD Fan Failure. An error signal was detected for the CCD fan.  
062-360 RAP Carriage Position Failure.  
062-362 RAP X Hard Failure.  
062-371 RAP Lamp Failure.  
062-380 RAP Platen AOC Failure.  
062-386 RAP Platen AOC Failure.  
062-389 RAP Carriage Over Run (Scan End).  
062-392 RAP IT/IPS Memory Failure.  
062-393 RAP IIT/IPS PWB Failure.  
062-790 RAP X Detect Failure.  
063-210 RAP Extension EEPROM Failure.  
063-220 RAP IPS-EXT Psync Failure.  
063-230 RAP EXT Image Parameter Failure.

063-240 RAP EXT Image Parameter Failure.  
065-210 RAP Extension Page Memory Failure 1.  
065-211 RAP CIS Shading FROM Failure  
065-212 RAP CIS Shading Level Failure.  
065-213 RAP CIS Output Level Failure.  
065-215 RAP Extension Page Memory Failure 2.  
065-216 RAP Extension Page Memory Failure 3.  
065-219 RAP CIS Black White Level Failure.  
065-220 RAP 1P DUP PWB-EXT Psync Failure.  
071-101 RAP Feed Out Sensor 1 is not turned ON.  
071-104 RAP Pre Registration Sensor ON Jam (Tray 1).  
071-105 RAP Registration Sensor ON Jam (Tray 1).  
071-210 RAP Tray 1 Lift Up Failure.  
072-101 RAP Tray 2 Miss Feed Jam.  
072-102 RAP The Tray 1 Feed Out Sensor does not turn ON.  
072-104 RAP Pre-Registration Sensor ON Jam (Tray 2).  
072-105 RAP Registration Sensor ON Jam (Tray 2).  
072-210 RAP Tray 2 Lift Up Failure.  
073-101 RAP Tray 3 Miss Feed Jam.  
073-102 RAP Feed Out Sensor 1 ON Jam (Tray 3).  
073-104 RAP Pre Registration Sensor ON Jam (Tray 3).  
073-105 RAP Registration Sensor ON Jam (Tray 3).  
073-210 RAP Tray 3 Lift Up Failure.  
074-101 RAP Pre Feed Sensor 4 is not ON within the specified time after the start of feed from Tray 4.  
074-102 RAP Feed Out Sensor 1 ON Jam (Tray 4).  
074-103 RAP The Tray 4 Feed Out Sensor is not ON within the specified time for paper fed from Tray 4.  
074-104 RAP Pre Registration Sensor ON Jam (Tray 4).  
074-105 RAP Registration Sensor ON Jam (Tray 4).  
074-210 RAP Tray 4 Lift Up Failure.  
075-100 RAP Tray 5/Bypass Pre Feed Sensor is not ON within the specified time after the start of feed from Tray 5.  
075-101 RAP Tray 5/Bypass Feed Out Sensor is not ON within the specified time for paper fed from Tray 5.  
075-109 RAP Paper from Tray 5/Bypass does not turn ON Pre Regi Sensor within a specified time.  
075-135 RAP Paper from Tray 5/Bypass does not turn ON Regi Sensor within a specified time.  
075-210 RAP Tray 5/Bypass Lift Up Sensor does not turn ON within a specified time after Tray 5 begins to lift.  
075-211 RAP Tray 5/Bypass Lift Down Sensor does not turn ON within a specified time after Tray 5 begins to lower.  
077-102 RAP Paper from Tray 2 did not turn on the Transport Path Sensor 1 within the specified time.  
077-103 RAP The Fuser Exit Sensor did not turn off within the specified time in straight exit mode.

077-106 RAP The Fuser Exit Sensor did not come on within the specified time after the Registration Motor.

077-107 RAP The Fuser Exit Sensor did not turn off within the specified time in invert exit mode.

077-109 RAP The IOT Exit Sensor did not come on at the specified time in non-invert mode.

077-111 RAP The IOT Exit Sensor did not come on within the specified time in invert exit mode.

077-113 RAP The IOT Exit Sensor did not turn off at the specified time in non-invert mode.

077-115 RAP The IOT Exit Sensor did not turn off within the specified time in invert exit mode.

077-118 RAP Paper from Duplex did not turn on the Pre Regi Sensor within the specified time.

077-120 RAP Post 2nd BTR Sensor On JAM.

077-123 RAP Duplex In Sensor does not turn ON a spec time after the start of invert.

077-129 RAP Paper from Duplex did not turn on the Regi Sensor within the specified time.

077-130 RAP Duplex Out Sensor does not turn ON within a specified time after Duplex In Sensor turns ON.

077-300 RAP The Front Cover is open.

077-301 RAP The Left Hand Interlock is open.

077-302 RAP The Right Hand Cover Interlock is open.

077-303 RAP PH Drawer Interlock Open.

077-304 RAP The Tray 5/Bypass Cover Interlock is open.

077-312 RAP Feeder Communication Failure.

077-909 RAP One of the IOT sensors detected paper when power was turned on or when an interlock was closed.

077-967 RAP The specified paper type and the paper type being used are different.

077-968 RAP The type of paper in the tray was changed.

078-100 RAP Paper from Tray 6 does not turn ON Pre Regi Sensor within a specified time.

078-101 RAP The Tray 6 Feed Out sensor is not ON within the specified time for paper fed from Tray 6.

078-102 RAP Paper from Tray 6 does not turn ON the Regi Sensor within a specified time.

078-151 RAP The Tray 6 Feed Out Sensor did not come on within the specified time after the start of feed.

078-250 RAP HCF Tray #2 Lift Up Fail.

078-300 RAP The HCF transport interlock is open.

078-301 RAP HCF Side Out Interlock Open.

089-600 RAP Incorrect Fast Scan positioning for the reference color Cyan was detected during fine adjustment.

089-601 RAP The Inner MOB Sensor failed to detect the fine-adjustment patterns properly during fine adjustment.

089-602 RAP The CENTER MOB Sensor failed to detect the fine-adjustment patterns properly during fine adjustment.

089-603 RAP The OUTER MOB Sensor failed to detect the fine-adjustment patterns properly during fine adjustment.

089-604 RAP The INNER MOB Sensor failed to detect the rough-adjustment patterns properly during Yellow rough adjustment.

089-605 RAP The CENTER MOB Sensor failed to detect the rough-adjustment patterns properly during Yellow rough adjustment.

089-606 RAP The OUTER MOB Sensor failed to detect the rough-adjustment patterns properly during Yellow rough adjustment.

089-607 RAP The INNER MOB Sensor failed to detect the rough-adjustment patterns correctly during Magenta rough adjustment.

089-608 RAP The CENTER MOB Sensor failed to detect the rough-adjustment patterns properly during Magenta rough adjustment.

089-609 RAP The OUTER MOB Sensor failed to detect the rough-adjustment patterns properly during Magenta rough adjustment.

089-610 RAP The INNER MOB Sensor failed to detect the rough-adjustment patterns properly during Cyan rough adjustment.

089-611 RAP The CENTER MOB Sensor failed to detect the rough-adjustment patterns properly during Cyan rough adjustment.

089-612 RAP The MOB Sensor OUT failed to detect the rough-adjustment patterns properly during Cyan rough adjustment.

089-613 RAP The INNER MOB Sensor failed to detect the rough-adjustment patterns properly during Black rough adjustment.

089-614 RAP The CENTER MOB Sensor failed to detect the rough-adjustment patterns properly during Black rough adjustment.

089-615 RAP The MOB Sensor OUT failed to detect the rough-adjustment patterns properly during Black rough adjustment.

089-616 RAP RC Data OverFlow Failure.

089-617 RAP RC Data OverRange Failure.

091-311 RAP The voltage level of the CC cleaner position sensor did not change within the specified time.

091-312 RAP Charge (K) Preclean HVPS has failed.

091-313 RAP DRUM CRUM ASIC Communication Failure.

091-320 RAP Charge Corotron Wire is broken.

091-400 RAP The replacement date for Waste Toner Bottle (regular) is near.

091-401 RAP The black drum cartridge is near the end-of-life.

091-403 RAP The CC Assembly is near the end-of-life.

091-404 RAP The CC Assembly has reached the end-of-life.

091-411 RAP The yellow drum cartridge is near the end-of-life.

091-421 RAP The magenta drum cartridge is near the end-of-life.

091-431 RAP The cyan drum cartridge is near the end-of-life.

091-910 RAP The waste toner bottle is not present.

091-911 RAP The waste toner bottle is full.

091-913 RAP The black drum cartridge (K) has reached the end-of-life.

091-914 RAP Communication failure between the MCU and the black Drum CRUM.

091-915 RAP The MCU detected incorrect data in the black drum cartridge CRUM.

091-916 RAP The CRUM authentication registration data on the drum cartridge is incorrect.

091-917 RAP MCU cannot communicate with the CRUM in drum Y.

091-918 RAP Communication failure with the magenta Drum CRUM.

091-919 RAP Communication failure with the cyan Drum CRUM.

091-920 RAP The MCU detected incorrect data in the Yellow drum cartridge CRUM.

091-921 RAP Drum CRUM is disconnected.

091-922 RAP Wrong Data in magenta drum cartridge.

091-923 RAP Wrong data in cyan drum cartridge.

091-924 RAP The CRUM authentication registration data on the yellow drum cartridge is incorrect.

091-925 RAP Wrong data in yellow Magenta cartridge.

091-926 RAP The CRUM authentication registration data on the cyan drum cartridge is incorrect.

091-927 RAP Yellow Drum CRUM is disconnected.

091-928 RAP Magenta Drum CRUM is disconnected.

091-929 RAP Cyan Drum CRUM is disconnected.  
091-932 RAP The yellow drum cartridge (Y) has reached the end-of-life.  
091-933 RAP The magenta drum cartridge (M) has reached the end-of-life.  
091-934 RAP The cyan drum cartridge (C) has reached the end-of-life.  
092-649 RAP The MOB ADC Shutter remains open due to shutter failure.  
092-650 RAP The MOB ADC Shutter remains closed due to shutter failure.  
092-651 RAP The output read by ADC Sensor from the clean Photoreceptor surface is out of range.  
092-652 RAP The measured ADC Patch density is light. (Over 75% of Vclean).  
092-653 RAP ATC SNR-Yellow output signal failure.  
092-654 RAP ATC SNR-Magenta output signal failure.  
092-655 RAP ATC SNR-Cyan output signal failure.  
092-656 RAP ATC SNR-black output signal failure.  
092-657 RAP The amplitude of ATC Yellow Sensor output is out of range.  
092-658 RAP The amplitude of ATC Magenta Sensor output is out of range.  
092-659 RAP The amplitude of ATC Cyan Sensor output is out of range.  
092-660 RAP The amplitude of ATC Black Sensor output is out of range.  
092-661 RAP The temperature output of the environment sensor is out of range.  
092-662 RAP The humidity output of the environment sensor is out of range.  
092-663 RAP The two levels of ADC Patch density created in Mini-Setup are reversed.  
093-300 RAP Marking Drawer Interlock Open.  
093-313 RAP The Low Toner Sensor failed to detect any toner after the Toner Cartridge Motor was energized.  
093-314 RAP Yellow Dispense failure.  
093-315 RAP Magenta Dispense failure.  
093-316 RAP Cyan Dispense failure.  
093-317 RAP Black Dispense failure.  
093-320 RAP There was a problem with the developer motor rotation.  
093-421 RAP The Black Toner Cartridge (K1) is empty and the Black Toner Cartridge (K2) is near empty.  
093-422 RAP The Black Toner Cartridge (K2) is empty and the Black Toner Cartridge (K1) is near empty.  
093-423 RAP Yellow toner is near empty.  
093-424 RAP Magenta toner is near empty.  
093-425 RAP Cyan toner empty.  
093-600 RAP Yellow Dispense near failure.  
093-601 RAP Magenta Dispense near failure.  
093-602 RAP Cyan Dispense near failure.  
093-603 RAP Black Dispense near failure.  
093-912 RAP The Black Dispense Motor rotation timed out indicating that the Black Cartridge and Reserve Tank are empty.  
093-918 RAP A communication failure with Black Toner Cartridge CRUM K2.

093-924 RAP A communication failure with Black Toner Cartridge CRUM K1.  
093-925 RAP The data written to the toner CRUM K1 did not agree with the data read.  
093-926 RAP Toner Cartridge CRUM K1 Authentication Data is different.  
093-927 RAP A communication failure with Yellow Toner Cartridge CRUM Y.  
093-928 RAP A communication failure with Magenta Toner Cartridge CRUM M.  
093-929 RAP A communication failure with Cyan Toner Cartridge CRUM C.  
093-932 RAP Cartridge Exchange Time Over.  
093-934 RAP The data written to the toner CRUM M did not agree with the data read.  
093-935 RAP The data written to the toner CRUM C did not agree with the data read.  
093-936 RAP The data written to the toner CRUM K2 did not agree with the data read.  
093-937 RAP Toner Cartridge CRUM Y Authentication Data is different.  
093-938 RAP Toner Cartridge CRUM M Authentication Data is different.  
093-939 RAP Toner Cartridge CRUM C Authentication Data is different.  
093-940 RAP Toner Cartridge CRUM K2 Authentication Data is different.  
094-320 RAP Retraction was not detected within the specified time after retraction of the 1st BTR started.  
094-321 RAP First BTR Contact Failure.  
094-322 RAP Second BTR Retract Failure.  
094-323 RAP Contact was not detected within the specified time after contact with the 2nd BTR started.  
102-356 RAP Fatal error related to the EWS.  
102-380 RAP Fatal error in the MF UI count.  
102-381 RAP ESS error during communication between ESS and the control panel.  
102-382 RAP A verification message was not returned from the Control Panel within the specified time.  
112-700 RAP The punch dust box is full.  
116-210 RAP Media Reader Fatal Error.  
116-211 RAP Media Reader Cable disconnected.  
116-212 RAP [Media Reader] MediaLib SW Logic Failure.  
116-310 RAP An error was detected while checking ESS font ROM DIMM #1.  
116-312 RAP An error was detected in the HDD encryption key during activation.  
116-313 RAP An encryption key was specified but the HDD itself was not encrypted.  
116-314 RAP An ethernet error was detected.  
116-315 RAP An error was detected during System Memory 1 R/W.  
116-316 RAP An error was detected during System Memory 2 R/W.  
116-317 RAP An error was detected when checking the MF ROM.  
116-318 RAP An error was detected when checking the expansion ROM R2.  
116-321 RAP System Software Fatal Error.  
116-322 RAP WebDAV S/W Failure.  
116-323 RAP An error was detected during the ESS PWB NVM Read/Write Check.

116-324 RAP A fatal software exception error has occurred in the Controller PWB CPU.  
116-325 RAP An error occurred in ESS fan rotation.  
116-329 RAP A system call error related to the serial I/F was detected.  
116-330 RAP Error during HDD check.  
116-331 RAP An error related to the log was detected.  
116-332 RAP An error in the MF ROM ( ) was detected.  
116-333 RAP A problem occurred during software processing, and processing could no longer continue.  
116-336 RAP Redirector HD Failure. A problem was detected during HD access.  
116-337 RAP Fatal error with SNTP in general.  
116-338 RAP Fatal error with JBA in general.  
116-340 RAP There was insufficient page memory, input buffers, or work area.  
116-341 RAP Incorrect version or invalid combination ROM DIMMs are installed.  
116-342 RAP Fatal error related to the SNMP agent.  
116-343 RAP An IC error within the ESS PWB was detected.  
116-346 RAP Formatter failure. Error return from a system call.  
116-348 RAP Redirector failure. Error return from a system call.  
116-349 RAP There was an error with a call within SIF related to Pflite.  
116-350 RAP Fatal error with AppleTalk in general.  
116-351 RAP Fatal error related to EtherTalk.  
116-352 RAP Fatal error related to NetWare.  
116-353 RAP A physical problem was detected with the HDD during activation, causing the HDD not to activate.  
116-354 RAP A problem with the HDD product code was detected during activation.  
116-355 RAP Fatal error related to the SNMP agent.  
116-356 RAP The HDD was formatted, but an HDD failure occurred.  
116-357 RAP PostScript fatal system error.  
116-358 RAP Fatal error related to the salutation.  
116-359 RAP Fatal error in PLW.  
116-360 RAP Fatal error related to SMB.  
116-361 RAP SPL HDD fatal error. SpoolCont detected an error during HDD access.  
116-362 RAP SSDP software failure.  
116-363 RAP BMLinkS or print service software failure.  
116-364 RAP A timer error was detected.  
116-365 RAP SPL fatal error.  
116-366 RAP Report generator incorrect operation.  
116-367 RAP Parallel fatal error.  
116-368 RAP DumpPrint fatal error.  
116-370 RAP XJCL fatal error.

116-371 RAP PCL Decomposer Software Failure. PCL fatal error.  
116-373 RAP Fatal error related to Dynamic DNS.  
116-374 RAP AutoSW fatal error.  
116-376 RAP Port 9100 Software Fail.  
116-378 RAP Fatal error related to MCR.  
116-379 RAP Fatal error related to MCC.  
116-380 RAP An error was detected while checking ESS font ROM DIMM #1.  
116-381 RAP The ABL did not agree with the ABL version information in NVM, or the data was corrupted.  
116-382 RAP An ABL access to NVM or HDD failed.  
116-385 RAP Fatal error related to the IDC.  
116-388 RAP It was detected that no HD is installed.  
116-389 RAP The system detected that no additional RAM was installed.  
116-390 RAP A version mismatch was detected between the standard ROM and NVM.  
116-391 RAP Incorrect specification of the country code, territory code, or paper size group.  
116-395 RAP Fatal error related to the USB.  
116-701 RAP Duplex printing is not possible due to insufficient memory.  
116-702 RAP Printing occurred with a substitute font.  
116-703 RAP PostScript data problem during PostScript grammar interpretation or language interpretation.  
116-704 RAP MediaReader No Insert (No Job).  
116-705 RAP MediaReader Format Error (No Job).  
116-706 RAP MediaReader: File Attribute Read Error (No Job).  
116-707 RAP MediaReader: Image File Read Error (No Job).  
116-708 RAP MediaReader: File Attribute Read Error (In Job).  
116-709 RAP MediaReader: Image File Read Error (Occurs during job).  
116-710 RAP Original size not correctly determined.  
116-711 RAP Mismatch in size and direction or ART EX form with paper to be printed.  
116-712 RAP PLW form / logo data cannot be registered due to insufficient RAM or HD space.  
116-713 RAP The job was divided because the HDD was full.  
116-714 RAP An HP-GL/2 (option) command error occurred.  
116-715 RAP The form could not be registered because the ART EX form registration upper limit was reached.  
116-716 RAP MediaReader File Does Not Exist.  
116-717 RAP MediaLib: Not Execute of New Request.  
116-718 RAP The specified ART EX form has not been registered.  
116-720 RAP PCL Memory Low, Page Simplified.  
116-737 RAP User defined data could not be registered because there was insufficient ART IV user definition memory.  
116-738 RAP Synthesis problem due to the specified ART IV form size and direction were different from the paper size and direction.  
116-739 RAP Form / logo data could not be registered because there was insufficient ART IV memory or HDD capacity.

116-740 RAP An error occurred because the print data exceeded the printer limit.

116-741 RAP No more forms can be registered because the number of ART IV Forms registered has reached the upper limit.

116-742 RAP No more logo data can be registered because the number of ART IV log data registered has reached the upper limit.

116-743 RAP The form or logo data could not be registered due to insufficient ART IV memory.

116-745 RAP An ART IV command error occurred.

116-746 RAP The specified form has not been registered.

116-747 RAP The paper margin value is too large for the HP-GL/2 (option) effective coordinate area.

116-748 RAP The HP-GL/2 (option) print data does not contain any image data.

116-749 RAP The specified PostScript font is not in ROM or HDD.

116-771 RAP Invalid JBIG Parameter DL Fixed.

116-772 RAP Invalid JBIG Parameter D Fixed.

116-773 RAP Invalid JBIG Parameter P Fixed.

116-774 RAP Invalid JBIG Parameter YD Fixed.

116-775 RAP Invalid JBIG Parameter LO Fixed.

116-776 RAP Invalid JBIG Parameter MX Fixed.

116-777 RAP Invalid JBIG Parameter MY Fixed.

116-778 RAP Invalid JBIG Parameter VLENGTH Fixed.

116-780 RAP There was a problem with the document attached to the received mail.

116-790 RAP Stapling was cancelled.

123-200 RAP The data received from ESS exceeded the buffer size of the storage destination within the control panel.

123-201 RAP Data intended to be received from the control panel exceeded the buffer size of the storage destination within the control panel.

123-202 RAP Events occurred that exceeded the processing capability for requests generated within the control panel.

123-203 RAP UI Debug code.

123-204 RAP SIO Parameter Failure (UI-Control panel).

123-205 RAP SIO Command Failure (UI-Control panel).

123-206 RAP SIO Status Failure (UI-Control panel).

123-207 RAP Comm Manager Target Failure (UI-Control panel).

123-208 RAP Comm Manager Command Failure (UI-Control panel).

123-209 RAP EVM Returns Wrong Value (UI-Control panel).

123-310 RAP Send Queue Full (UI-Control panel).

123-311 RAP Receive Queue Full (UI-Control panel).

123-312 RAP EVM Uses Wrong API (UI-Control panel).

123-313 RAP AS Uses Wrong API (UI-Control panel).

123-314 RAP Event-Waiting Timer Timeout (UI-Control panel).

123-315 RAP CTS Internal Failure (UI-Control panel).

123-316 RAP Send Request Queue Full SIO (UI-Control panel).

123-317 RAP Receive Message Queue Full (UI-Control panel).

123-318 RAP Receive Finish Queue Full (UI-Control panel).  
123-319 RAP Send Failure with No ACK (UI-Control panel).  
123-320 RAP Polling Failure (UI-Control panel).  
123-321 RAP Send Message Failure (UI-Control panel).  
123-322 RAP Target Failure (UI-Control panel).  
123-323 RAP Address Failure (UI-Control panel). Serial communication error.  
123-324 RAP Size Failure (UI-Control panel). Serial communication error.  
123-325 RAP Object Creation Failure (UI-Control panel).  
123-326 RAP Memory Overflow (UI-Control panel).  
123-327 RAP Button Overflow (UI-Control panel).  
123-328 RAP UI Internal Failure with Out of Area.  
123-329 RAP UI Internal Failure with Invalid Coordinates.  
123-330 RAP Interface Failure with Invalid Parameter LCD.  
123-331 RAP UI Internal Failure with Invalid LED Request.  
123-332 RAP I/F Failure (Invalid Parameter CP).  
123-333 RAP I/F Failure (No Communication).  
123-334 RAP I/F Failure (Receiving Error Key Code).  
123-335 RAP I/F Failure (Receiving Invalid Coordinates).  
123-336 RAP I/F Failure (DM-ACD Drv. I/F).  
123-337 RAP Frame Data Error with Invalid Data Type.  
123-338 RAP Frame Data Error Offset Address Out.  
123-339 RAP Display Request Code Invalid.  
123-340 RAP Interface Failure GUAM-DM I/F.  
123-341 RAP Event Queue Full (UI-Control panel).  
123-342 RAP Event Queue Empty (UI-Control panel).  
123-343 RAP Invalid Class (UI-Control panel).  
123-344 RAP Invalid Type (UI-Control panel).  
123-345 RAP Timer Queue Full (UI-Control panel).  
123-346 RAP Invalid Timer Number (UI-Control panel).  
123-347 RAP Undefined Trap (UI-Control panel).  
123-348 RAP Command Access Exception (UI-Control panel).  
123-349 RAP Invalid Command (UI-Control panel).  
123-350 RAP Privilege Command (UI-Control panel).  
123-351 RAP No FPU Exception (UI-Control panel).  
123-352 RAP Address Mis-align (UI-Control panel).  
123-353 RAP Data Access Exception (UI-Control panel).  
123-354 RAP Tag Overflow (UI-Control panel).

123-355 RAP No Co Processor Exception (UI-Control panel).  
123-356 RAP Short of Area (UI-Control panel).  
123-357 RAP Cancel Wait Status (UI-Control panel).  
123-358 RAP Timeout (UI-Control panel).  
123-359 RAP Queue Overflow (UI-Control panel).  
123-360 RAP Context Failure (UI-Control panel).  
123-361 RAP Object Failure (UI-Control panel).  
123-362 RAP No Object (UI-Control panel).  
123-363 RAP Invalid ID (UI-Control panel).  
123-364 RAP Parameter Failure (UI-Control panel).  
123-365 RAP Reserve Attribute (UI-Control panel).  
123-366 RAP Reserve Function Code (UI-Control panel).  
123-367 RAP Unsupported Function (UI-Control panel).  
123-368 RAP Short of UI Memory (UI-Control panel).  
123-369 RAP Invalid Interface Value (UI-Control panel).  
123-370 RAP Interface Length Failure (UI-Control panel).  
123-371 RAP Interface Parameter Failure (UI-Control panel).  
123-372 RAP Interface Sequence Failure (UI-Control panel).  
123-373 RAP Channel Failure (UI-Control panel).  
123-374 RAP Invalid User Job ID (UI-Control panel).  
123-375 RAP Internal Resource Failure (UI-Control panel).  
123-376 RAP Internal Memory Failure (UI-Control panel).  
123-377 RAP UI Timer Failure (UI-Control panel).  
123-378 RAP Interface Format Failure (UI-Control panel).  
123-379 RAP Dispatch Failure (UI-Control panel).  
123-380 RAP Copy Interface Failure (UI-Control panel).  
123-382 RAP Scanner Interface Failure (UI-Control panel).  
123-383 RAP Report Interface Failure (UI-Control panel).  
123-384 RAP Server Access Failure (UI-Control panel).  
123-385 RAP Service Object Overflow (UI-Control panel).  
123-386 RAP Invalid Service Object (UI-Control panel).  
123-387 RAP Invalid Service Object Attribute (UI-Control panel).  
123-388 RAP Attribute Failure (UI-Control panel).  
123-389 RAP Argument Failure (UI-Control panel).  
123-390 RAP Job Parameter Failure (UI-Control panel).  
123-391 RAP Job Actual Parameter Failure (UI-Control panel).  
123-392 RAP Auditron Failure (UI-Control panel).

123-393 RAP EP Failure (UI-Control panel).  
123-394 RAP File Access Failure (UI-Control panel).  
123-395 RAP NVM Failure (UI-Control panel).  
123-396 RAP FF Failure (UI-Control panel).  
123-397 RAP MGR Failure (UI-Control panel).  
123-398 RAP Delay Release Queue Full (UI-Control panel).  
123-399 RAP Internal Failure (UI-Control panel).  
123-400 RAP Internal Failure (UI-Control panel).  
124-310 RAP DC132 11 - The product number was not specified.  
124-311 RAP DC132 09 - The serial number registration field failed.  
124-312 RAP DC132 12 - Product numbers did not agree.  
124-313 RAP DC132 10 - Serial numbers did not agree.  
124-314 RAP DC 132-01 - IOT Speed Failure.  
124-315 RAP DC 132-02 - IOT Speed Mismatch.  
124-316 RAP DC 132-04 - Product a/f Model Failure.  
124-317 RAP DC 132-04 - Product a/f All Product Model Mismatch.  
124-318 RAP Product Type for S/W Key Failure.  
124-319 RAP DC 132-08 - All Product Type For S/W Key Mismatch.  
124-320 RAP EEP ROM Failure.  
124-321 RAP Backup SRAM Failure. An NVM ROM write problem occurred on the ESS PWB.  
124-322 RAP DC 132-05 - Copy/Scan/Print S/W Key by PWE Failure.  
124-323 RAP DC 132-06 - Copy/Scan/Print S/W Key 1 Failure.  
124-324 RAP All Billings Mismatch.  
124-325 RAP Billing Restoration Failure.  
124-333 RAP ASIC Failure (Panther).  
124-334 RAP Standard Font ROM Error.  
124-335 RAP Font ROM Not Found.  
124-337 RAP ESS Standard RAM Error.  
124-338 RAP Same Font ROMs Found.  
124-339 RAP ROM DIMM of another product found.  
124-340 RAP The three CRUM market destination values are not set up (0 or different).  
124-341 RAP One CRUM market destination value is different (IOT).  
124-342 RAP One CRUM market destination value is different (SYS 1).  
124-343 RAP One CRUM market destination value is different (SYS 2).  
124-350 RAP The three CRUM OEM destination values are not set up (0 or different).  
124-351 RAP One CRUM OEM destination value is different (IOT).  
124-352 RAP One CRUM OEM destination value is different (SYS 1).

124-353 RAP One CRUM OEM destination value is different (SYS 2).  
124-360 RAP CRUM Valid/Invalid is not set up at the three locations (0 or different values).  
124-361 RAP CRUM Validation Failure MCU.  
124-362 RAP CRUM Validation Failure SYS 1.  
124-363 RAP CRUM Validation Failure SYS 2.  
124-372 RAP IOT sc Soft Failure.  
124-373 RAP IOT Manager SW Failure.  
124-374 RAP IOT IM Device Driver SW Failure.  
124-380 RAP CRUM Market fail ALL (2).  
124-381 RAP CRUM Market fail MCU (2).  
124-382 RAP CRUM Market fail SYS 1 (2).  
124-383 RAP CRUM Market fail SYS 2 (2).  
124-390 RAP CRUM OEM fail ALL (2).  
124-391 RAP CRUM OEM fail MCU (2).  
124-392 RAP CRUM OEM fail SYS 1 (2).  
124-393 RAP CRUM OEM fail SYS 2 (2).  
124-701 RAP Side Tray to Center Tray.  
124-704 RAP The output tray was changed from the Folder Tray to the Center Tray and printing continued.  
124-705 RAP Punching Cancelled.  
124-706 RAP Folding Cancelled.  
124-708 RAP The output tray has been changed to the Sub Tray because a failure was detected in the specified output tray.  
124-709 RAP Stapler Sheet Count is too high.  
125-311 RAP PSWcont Unexpected Failure.  
127-210 RAP DFE Communication Failure.  
127-211 RAP DFE Parameter Error.  
127-212 RAP ExtPrint Check Mode Error.  
127-213 RAP External Print IF Mismatch.  
127-220 RAP Communication Error (video) detected by the DFE.  
127-221 RAP Communication Error (Command) detected by the DFE.  
127-310 RAP ESR Task Fatal Error.  
127-311 RAP ExtPRT.  
127-320 RAP DFE Critical Failure.  
127-337 RAP Job Template HDD Write Error.  
127-342 RAP Job Template Monitor Failure.  
127-353 RAP LPD Soft Fatal Error.  
127-354 RAP FTP Server Software Failure.  
127-396 RAP Mail I/O Soft Fatal error.

127-398 RAP IPP Soft Fatal Error.  
127-399 RAP JME Soft Fatal Error.  
202-399 RAP Timer Internal Fail.